

Laptop 8.0 build XXXX: Card Authentication Matrix - Windows XP SP3 with Client Utility

Card	Open	WEP-128	LEAP-WEP	PEAP-WEP	EAP-TLS-WEP	EAP-FAST-WEP	LEAP-WPA	PEAP-WPA	EAP-TLS-WPA	EAP-FAST-WPA	LEAP-WPA2	PEAP-WPA2	EAP-TLS-WPA2	EAP-FAST-WPA2	WPA-PSK-TKIP	WPA2-PSK-AES
AirMagnet 802.11a/b/g/n Wireless PC Card	Client Utility Currently Not Supported															
Gigabyte AirCruiser N300 Dual Mini Card (GN-WI06N-RH)	Client Utility Currently Not Supported															
Cisco21AG with ADU 4.1	P	P	P	P	P		P	P	P		P	P	P		P	P
Netgear WG511U	No Client Utility Available for Testing															
Proxim 8480abg	P	P	P	P	P										NS	NS
Ubiquiti SRC 300mW MMCX	P	P	P	P	P		P	P	P		P	P	P		NS	NS
Ubiquiti SR4C MMCX	Client Utility Currently Not Supported															
Ubiquiti SRX Express Card 300mW	Client Utility Currently Not Supported															
Intel 2915ABG	Client Utility Currently Not Supported															
Intel 3945ABG	P	P	P	P	P		P	P	P		P	P	P		P	P
OOO Model 02/e2 UMPC mini 802.11ABG	Client Utility Currently Not Supported															
NEC Aterm WL300NC (TELEC regions only)	Client Utility Currently Not Supported															
NEC Aterm WL54SU USB Adapter (TELEC regions only)	Client Utility Currently Not Supported															
D-Link DWL-AG132 USB adapter	Client Utility Currently Not Supported															
P: Pass NS: Not Supported F: Fails FC:Fails with Client Utility Blank: Not Tested																

LEAP-WEP: Users must have a profile configured in the client utility and configure Authentication type LEAP within AirMagnet

LEAP-WPA/WPA2: Users must have a profile configured in the client utility and configure Authentication type LEAP and check WPA within AirMagnet

PEAP-WEP,EAP-TLS-WEP, EAP-FAST-WEP Users must have a profile configured in client utility and select Authentication type Host Based EAP within AirMagnet

PEAP-WPA/WPA2,EAP-TLS-WPA/WPA2, EAP-FAST-WPA/WPA2: Users must have a profile configured in client utility and select Authentication type Host Based EAP and check WPA within AirMagnet

WPA-PSK-TKIP/AES: Users must have a profile configured in the client utility and select Authentication type WPA-PSK with AirMagnet

Laptop 8.0 build XXXX: Card Authentication Matrix - Windows XP SP3 with Windows Zero Configuration

Card	Open	WEP-128	LEAP-WEP	PEAP-WEP	EAP-TLS-WEP	EAP-FAST-WEP	LEAP-WPA	PEAP-WPA	EAP-TLS-WPA	EAP-FAST-WPA	LEAP-WPA2	PEAP-WPA2	EAP-TLS-WPA2	EAP-FAST-WPA2	WPA-PSK-TKIP	WPA2-PSK-AES
AirMagnet 802.11a/b/g/n Wireless PC Card	P	P	NS	P	P	NS	NS	P	P	NS	NS	P	P	NS	P	P
Gigabyte AirCruiser N300 Dual Mini Card (GN-WI06N-RH)	P	P	NS	P	P	NS	NS	P	P	NS	NS	P	P	NS	P	P
Cisco21AG with ADU 4.1	P	P	P	P	P	NS	NS	P	P	NS	NS	NS	NS	NS	NS	NS
Netgear WG511U	P	P	P	P	P	NS	NS	P	P	NS	NS	NS	NS	NS	NS	NS
Proxim 8480abg	P	P	P	P	P	NS	NS	P	P	NS	NS	NS	NS	NS	NS	NS
Ubiquiti SRC 300mW MMCX	P	P	P	P	P	NS	NS	P	P	NS	NS	NS	NS	NS	NS	NS
Ubiquiti SR4C MMCX	P	P	P	P	P	NS	NS	P	P	NS	NS	NS	NS	NS	NS	NS
Ubiquiti SRX Express Card 300mW	P	P	NS		P	NS	NS		P	NS	NS		P	NS	P	P
Intel 2915ABG	P	P	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS
Intel 3945ABG						NS	NS			NS	NS	NS	NS	NS	NS	NS
OOO Model 02/e2 UMPC mini 802.11ABG	P	P	P	P	P	NS	NS	P	P	NS	NS	NS	NS	NS	NS	NS
NEC Aterm WL300NC (TELEC regions only)	P	P	NS	P	P	NS	NS	P	P	NS	NS	P	P	NS	P	P
NEC Aterm WL54SU USB Adapter (TELEC regions only)			NS			NS	NS			NS	NS			NS		
D-Link DWL-AG132 USB adapter	P	P	NS	P	P	NS	NS	P	P	NS	NS			NS	P	P

P: Pass NS: Not Supported F: Fails FC:Fails with Client Utility Blank: Not Tested

WEP-128 and LEAP-WEP do not need to be configured in WZC.

PEAP-WEP,EAP-TLS-WEP Users must have a profile configured in WZC and select Authentication type Host Based EAP within AirMagnet

PEAP-WPA,EAP-TLS-WPA Users must have a profile configured in WZC and select Authentication type Host Based EAP and check WPA within AirMagnet

***: Need the Auto configuration Patch depending on the Service Pack (See Release Notes)

Laptop 8.0 build XXXX: Card Authentication Matrix - Windows Vista Ultimate and Business (SP1)

Card	Open	WEP-128	LEAP-WEP	PEAP-WEP	EAP-TLS-WEP	EAP-FAST-WEP	LEAP-WPA	PEAP-WPA	EAP-TLS-WPA	EAP-FAST-WPA	LEAP-WPA2	PEAP-WPA2	EAP-TLS-WPA2	EAP-FAST-WPA2	WPA-PSK-TKIP	WPA2-PSK-AES
AirMagnet 802.11a/b/g/n Wireless PC Card	P	P	NS	P	NS	NS	NS	P	NS	NS	NS	P	NS	NS	P	P
Gigabyte AirCruiser N300 Dual Mini Card (GN-WI06N-RH)	P	P	NS	P	NS	NS	NS	P	NS	NS	NS	P	NS	NS	P	P
Cisco21AG with ADU 4.1	P	P	NS	P	NS	NS	NS	P	NS	NS	NS	P	NS	NS	P	P
Netgear WG511U	P	P	NS	P	NS	NS	NS	P	NS	NS	NS	P	NS	NS	P	P
Proxim 8480abg	P	P	NS	P	NS	NS	NS	P	NS	NS	NS	P	NS	NS	P	P
Ubiquiti SRC 300mW MMCX	P	P	NS	P	NS	NS	NS	P	NS	NS	NS	P	NS	NS	P	P
Ubiquiti SR4C MMCX	P	P	NS	P	NS	NS	NS	P	NS	NS	NS	P	NS	NS	P	P
Ubiquiti SRX Express Card 300mW	Adapter not supported on Windows Vista															
Intel 2915ABG	Adapter not supported on Windows Vista															
Intel 3945ABG	Adapter not supported on Windows Vista															
OQO Model 02/e2 UMPC mini 802.11ABG	Adapter not supported on Windows Vista															
NEC Aterm WL300NC (TELEC regions only)	Adapter not supported on Windows Vista															
NEC Aterm WL54SU USB Adapter (TELEC regions only)	Adapter not supported on Windows Vista															
D-Link DWL-AG132 USB adapter	Adapter not supported on Windows Vista															
P: Pass NS: Not Supported F: Fails FC:Fails with Client Utility Blank: Not Tested																

PEAP authentication type is only supported without certificate.

Laptop 8.0 build XXXX: Card Authentication Matrix - Windows 2K with Client Utility

Card	Open	WEP-128	LEAP-WEP	PEAP-WEP	EAP-TLS-WEP	EAP-FAST-WEP	LEAP-WPA	PEAP-WPA	EAP-TLS-WPA	EAP-FAST-WPA	LEAP-WPA2	PEAP-WPA2	EAP-TLS-WPA2	EAP-FAST-WPA2	WPA-PSK-TKIP	WPA2-PSK-AES
AirMagnet 802.11a/b/g/n Wireless PC Card	Adapater not supported on Win2K															
Gigabyte AirCruiser N300 Dual Mini Card (GN-WI06N-RH)	Adapater not supported on Win2K															
Cisco21AG with ADU 4.1	P	P	P	P	P		P	P	P		P	P	P		P	P
Netgear WG511U	No Client Utility Available for Testing															
Proxim 8480abg	P	P	P	P	P										NS	NS
Ubiquiti SRC 300mW MMCX	P	P	P	P	P										NS	NS
Ubiquiti SR4C MMCX	Adapater not supported on Win2K															
Ubiquiti SRX Express Card 300mW	Adapater not supported on Win2K															
Intel 2915ABG	Adapater not supported on Win2K															
Intel 3945ABG	Adapater not supported on Win2K															
OQO Model 02/e2 UMPC mini 802.11ABG	Adapater not supported on Win2K															
NEC Aterm WL300NC (TELEC regions only)	Adapater not supported on Win2K															
NEC Aterm WL54SU USB Adapter (TELEC regions only)	Adapater not supported on Win2K															
D-Link DWL-AG132 USB adapter	Adapater not supported on Win2K															
P: Pass NS: Not Supported F: Fails FC:Fails with Client Utility Blank: Not Tested																

LEAP-WEP: Users must have a profile configured in the client utility and configure Authentication type LEAP within AirMagnet

LEAP-WPA/WPA2: Users must have a profile configured in the client utility and configure Authentication type LEAP and check WPA within AirMagnet

PEAP-WEP,EAP-TLS-WEP, EAP-FAST-WEP Users must have a profile configured in client utility and select Authentication type Host Based EAP within AirMagnet

PEAP-WPA/WPA2,EAP-TLS-WPA/WPA2, EAP-FAST-WPA/WPA2: Users must have a profile configured in client utility and select Authentication type Host Based EAP and check WPA within AirMagnet

WPA-PSK-TKIP/AES: Users must have a profile configured in the client utility and select Authentication type WPA-PSK with AirMagnet

Laptop 8.0 build XXXX: Card Authentication Matrix - Windows 2K

Card	Open	WEP-128	LEAP-WEP	PEAP-WEP	EAP-TLS-WEP	EAP-FAST-WEP	LEAP-WPA	PEAP-WPA	EAP-TLS-WPA	EAP-FAST-WPA	LEAP-WPA2	PEAP-WPA2	EAP-TLS-WPA2	EAP-FAST-WPA2	WPA-PSK-TKIP	WPA2-PSK-AES
AirMagnet 802.11a/b/g/n Wireless PC Card	Adapter not supported on Win2K															
Gigabyte AirCruiser N300 Dual Mini Card (GN-WI06N-RH)	Adapter not supported on Win2K															
Cisco21AG with ADU 4.1	P	P	P	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS
Netgear WG511U	P	P	P	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS
Proxim 8480abg	P	P	P	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS
Ubiquiti SRC 300mW MMCX	P	P	P	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS	NS
Ubiquiti SR4C MMCX	Adapter not supported on Win2K															
Ubiquiti SRX Express Card 300mW	Adapter not supported on Win2K															
Intel 2915ABG	Adapter not supported on Win2K															
Intel 3945ABG	Adapter not supported on Win2K															
OQO Model 02/e2 UMPC mini 802.11ABG	Adapter not supported on Win2K															
NEC Aterm WL300NC (TELEC regions only)	Adapter not supported on Win2K															
NEC Aterm WL54SU USB Adapter (TELEC regions only)	Adapter not supported on Win2K															
D-Link DWL-AG132 USB adapter	Adapter not supported on Win2K															
P: Pass NS: Not Supported F: Fails FC:Fails with Client Utility Blank: Not Tested																

**: WEP-128 and LEAP-WEP do not need to be configured in WZC.

PEAP-WEP,EAP-TLS-WEP Users must have a profile configured in WZC and select Authentication type Host Based EAP within AirMagnet

PEAP-WPA,EAP-TLS-WPA Users must have a profile configured in WZC and select Authentication type Host Based EAP and check WPA within AirMagnet