

## D-link Systems AirPremier DWL-AG132 Wireless 108AG USB adapter

Operating System	General Features								Supported Authentication for Active associations															
Operating System	Supported version (Previous versions or v 7.0?)	Passive Survey	Active Survey	802.11n 40 Mhz surveying capability	31 Channel scanning - 5 GHz	Extended Channel-5 GHz	Roaming Control for Active Surveys	Noise detection	Open	WEP-128	LEAP-WEP	PEAP-WEP	EAP-TLS-WEP	EAP-FAST-WEP	LEAP-WPA	PEAP-WPA	EAP-TLS-WPA	EAP-FAST-WPA	LEAP-WPA2	PEAP-WPA2	EAP-TLS-WPA2	EAP-FAST-WPA2	WPA-PSK-TKIP	WPA2-PSK-AES
Windows XP with client utility	Client utility not supported																							
Windows XP with Windows Zero config (WLAN API Patch/SP3)	Previously supported	Supp	Supp	NS	Supp	Future	NS	NS	Supp	Supp	NS	Supp	Supp	NS	NS	Supp	Supp	NS	NS	Supp	NS	NS	Supp	Supp
Windows Vista	Adapter not supported on Windows Vista																							

**NS: Not supported    Supp: Supported    Future:Future    NA: Not Applicable    PS: Partial Support**

Windows XP SP2 users: [Download XP WLAN API Patch from : http://www.microsoft.com/downloads/details.aspx?FamilyId=52A43BAB-DC4E-413F-AC71-158EFD1ADA50&displaylang=en](http://www.microsoft.com/downloads/details.aspx?FamilyId=52A43BAB-DC4E-413F-AC71-158EFD1ADA50&displaylang=en)  
 Windows XP SP3 users: [Do not install the Wireless LAN API Patch](#)

**Notes for Windows XP with Windows Zero Config:**  
 Configure wireless profiles in Windows Zero Config